

- Attach the cable adjuster to the bracket. Position the adjuster so that it is screwed all the way in. Do not tighten the lock nuts on the adjuster yet.



- Route the new 'carburettor' cable around and out the RHS of the bike under the frame rail as shown in the following photos.



Installing the Vacuum Actuator

- Mount the actuator on the RHS fairing support using the bracket provided and two bolts, nuts and flat washers. The mounting bracket fits on the inside face of the fairing bracket. The small plate fits on the outside and clamps the actuator to the faring frame.

